JB Weld Water Weld User Guide

Before applying roughen and clean the area to be repaired. Then fellow these easy steps:

1. Cut off required portion of material.
2. Twist and knead until uniform colour is achieved- no steaks.
3. Apply to surface to be repaired after mixing. Work time is 15-25 minutes until hardening begins.
4. Curing: After 60 minutes WaterWeld is fully cured.

WaterWeld adheres to most surfaces. Best results are achieved when the area is first roughened by sanding or filing to clean and prepare the surface. It is recommended that for cracks and small holes you should first sand and file this to allow for a larger surface area and so that the putty can penetrate through the entire surface and crack. A smooth finish can be obtained by rubbing application before hardening occurs.

WARNING:

- MAY BE HARMRL IF SWALLOWED. EYE IRRITANT. MAY IRRITAIT SKIN. EXPOSURE MAY CAUSS ALLERGIC REACTIONS.
- CONTAINS: EPOXY RESIN and TRIETHYLENETETRAMINE.
- PRECAIJTIONS: Avoid ingestion. Keep away tom eyes. Wash hands thoroughly with soap and water after use.
- KEEP OUT OF REACH OF CHILDREN.
- FIRST AID: It swallowed get prompt medical attention. If eye contact rinse with tap water for at least 5-10 minutes; seek medical care if irritation persists. If shin irritation occurs seek medical care.

Technical

- Contents: 57g (2oz)
- Sets in 15-25 minutes
- Cures in 60minutes
- Drinking water safe
- Mixed colour: Off white
- Made in USA
- Model no. 8277